




iXflash Q

Quick Start Guide for iPhone/iPad

1) Download App

Download and Install the free iXflash App from the Apple App Store.



4) The iXflash App should open once the iXflash Q is connected.

If not, tap the iXflash App that looks like this:



2) Insert Memory Card

Insert any microSD* card, up to 2TB, into the iXflash Q MicroSD Slot.



*MicroSD Card not included. Recommended to use a high-speed MicroSD card for best performance.

5) Backup & Restore

Touch the Backup & Restore icon to backup all or selected photos/videos stored on your iPhone/iPad and iCloud*



*Must be connected to the internet via Wi-Fi or Cellular Data to backup iCloud.

3) Connect to Your iPhone or iPad + Supports Passthrough Fast Charging capability:

3-1 If your iPhone/iPad has a USB-C connection

a. You can insert the USB-C male connector directly into your iPhone/iPad.



b. To charge, use a USB-C to USB-C cable. Connect one end to a charging cube or power bank, and the other end to the female USB-C port of the iXflash Q. The iXflash Q should be connected to your iPhone/iPad.



3-2 If your iPhone/iPad has a Lightning connection

You can use a USB-C to Lightning cable by inserting the Lightning end to your iPhone/iPad and the USB-C end to the female USB-C port of the iXflash Q. The male USB-C connector of the iXflash Q must be plugged into a power source, such as a charging cube or power bank, in order to work with Lightning devices.




6) Capture & Save Videos/Photos Directly onto the MicroSD card in the iXflash Q Drive

1. Touch the Camera icon
2. Record video(s) or take photo(s) through the iXflash App camera feature
3. All video(s) and image(s) will be stored directly onto the MicroSD Card inside the iXflash Q drive, without using the iPhone/iPad's internal memory



7) Watch All Your Videos with Ease

1. One touch to watch your last viewed video.
2. View playback history
3. User-friendly interface supports fast-forward / backward and volume adjustment simply by using the swipe and /or double-tap gestures, for example:



| Fast backward/forward 10 sec



| Adjust Brightness



| Adjust volume

8) File Manager

Able to view, move, play, and manage all files stored on the MicroSD Card inside the iXflash Q drive.





iXflash Q Quick Start Guide for iPhone/iPad

9) View and Manage Files on a Computer

- 1) Connect the USB side of the iXflash Q to any corresponding USB port* on a computer
- 2) Open the drive associated with the iXflash Q on the computer.
- 3) Access any files stored on the MicroSD card in the iXflash Q.

*Use adaptor for USB-A port if needed

10) Index of all iXflash Functions & Settings on the Home Screen



Camera icon :

Record live videos & take pictures that will be stored directly onto the MicroSD card in the iXflash Q.



Photos / Videos icon :

Shortcut to all pictures/videos stored on the MicroSD Card inside the iXflash Q and iXflash App on the iPhone/iPad.



iXflash icon :

View and manage all content stored on the MicroSD card inserted into the iXflash Q.



iPhone icon :

View and manage all content temporarily stored on the iXflash App located on your device.



Favorite icon :

View the list of files that you marked as favorite(s).



Backup & Restore icon :

Backup or restore all contacts, videos and photos from/to an iPhone/iPad.



Settings :

Adjust settings for the iXflash Q.



Continue icon :

One touch to continue viewing or playing the last file or media you opened.

